

KENWOOD

DNX9190DABS
DNX7190DABS
DNX5190DABS
DNX419DABS
DNR4190DABS
DNR3190BTS

GPS NAVIGATION SYSTEM

INSTRUCTION MANUAL

JVCKENWOOD Corporation

All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organisation of such changes or improvements. Go to www.garmin.com for current updates and additional information concerning the use of this product.

Software Licence Agreement

BY USING THE DNX9190DABS / DNX7190DABS / DNX5190DABS / DNX419DABS / DNR4190DABS / DNR3190BTS, YOU AGREE TO BE BOUND BY THE TERMS AND CONDITIONS OF THE FOLLOWING SOFTWARE LICENCE AGREEMENT. PLEASE READ THIS AGREEMENT CAREFULLY.

Garmin Ltd. and its subsidiaries ("Garmin") grant you a limited licence to use the software embedded in this device (the "Software") in binary executable form in the normal operation of the product. Title, ownership rights and intellectual property rights in and to the Software remain in Garmin and/or its third-party providers.

You acknowledge that the Software is the property of Garmin and/or its third-party providers and is protected under the United States of America copyright laws and international copyright treaties. You further acknowledge that the structure, organisation and code of the Software, for which source code is not provided, are valuable trade secrets of Garmin and/or its third-party providers and that the Software in source code form remains a valuable trade secret of Garmin and/or its third-party providers. You agree not to decompile, disassemble, modify, reverse assemble, reverse engineer or reduce to human readable form the Software or any part thereof or create any derivative works based on the Software. You agree not to export or re-export the Software to any country in violation of the export control laws of the United States of America or the export control laws of any other applicable country.

End User Licence Agreement

The infotainment system you have purchased for your vehicle may contain a navigation solution ("Navigation Solution"). The software embedded in the Navigation Solution (the "Software") is owned by the navigation solution provider or its subsidiaries (collectively, "Navigation Provider"). The map data that may be embedded in your Navigation Solution or downloaded separately (the "Map Data") is either owned by the Navigation Provider, or by HERE North America LLC, HERE Global B.V. and/or its affiliates ("HERE"), or another third party and licensed to the Navigation Provider. The Navigation Provider also owns, or licenses from third-party providers, information, traffic data, text, images, graphics, photographs, audio, video, images and other applications and data that may be embedded in the Navigation Solution, or downloaded separately ("Other Content"). The Map Data and Other Content are collectively the "Content". The Software and Content (collectively, the "Navigation Provider Products") are protected under copyright laws and international copyright treaties. The Navigation Provider Products are licensed, not sold. The structure, organisation and code of the Software are valuable trade secrets of the Navigation Provider and/or its third-party providers. The Navigation Provider Products are each provided under this Licence Agreement and are subject to the following terms and conditions which are agreed to by the End User ("you" or "your"), on the one hand, and the Navigation

Provider and its licensors and affiliated companies of the Navigation Provider and its licensors, on the other hand. The Navigation Provider's licensors, including the licensors, service providers, channel partners, suppliers and affiliated companies of the Navigation Provider and its licensors, are each a direct and intended third-party beneficiary of this Agreement and may enforce their rights directly against you in the event of your breach of this Agreement.

IMPORTANT: CAREFULLY READ THIS ENTIRE LICENCE AGREEMENT BEFORE PURCHASING OR USING YOUR NAVIGATION SOLUTION OR CONTENT. PURCHASING, INSTALLING, COPYING, OR OTHERWISE USING YOUR NAVIGATION SOLUTION OR CONTENT CONSTITUTES YOUR ACKNOWLEDGMENT THAT YOU HAVE READ THIS LICENCE AGREEMENT AND AGREE TO ITS TERMS AND CONDITIONS.

Licence terms and conditions

The Navigation Provider grants you a limited, non-exclusive licence to use the applicable Navigation Provider Product in accordance with the terms of this Agreement. You agree to use the applicable Navigation Provider Product for solely personal use, or if applicable, for use in your business' internal operations, and not for service bureau, time-sharing, resale or other similar purposes. You agree not to otherwise reproduce, archive, copy, modify, decompile, disassemble, reverse engineer or create derivative works of any portion of the Navigation Solution, and may not transfer or distribute it in any form, for any purpose, except to the extent permitted by mandatory laws. The Navigation Provider also reserves the right to discontinue offering any Content supplied by any third-party supplier if such supplier ceases to supply such content or the Navigation Provider's contract with such supplier terminates for any reason.

Restrictions. Except where you have been specifically licensed to do so by the Navigation Provider, and without limiting the preceding paragraphs, you may not use the Navigation Provider Products with any products, systems, or applications installed or otherwise connected to or in communication with vehicles, and which are capable of dispatch, fleet management or similar applications where the Content is used by a central control centre in dispatching a fleet of vehicles. In addition, you are prohibited from renting or leasing the Navigation Provider Products to any other person or third party.

You agree to be fully responsible for your own conduct and content while using the Software and for any consequences thereof. You agree to use the Software only for purposes that are legal, proper and in accordance with this Agreement and any applicable policies or guidelines. By way of example, and not as a limitation, you agree that when using the Software, you will not:

- upload, post, email or transmit or otherwise make available content that infringes any patent, trademark, copyright, trade secret or other proprietary right of any party, unless you are the owner of the rights or have the permission of the owner to post such Content;
- use the Software or other content for any illegal or unauthorised purpose; or
- transmit any viruses, worms, defects, Trojan horses, or any items of a destructive nature.

In the event that you are located outside of the United States, you agree to comply with any laws, rules or regulations in your locale or in the location of your web server regarding online

conduct and acceptable content, including laws regulating the export of data to the United States or your country of residence.

No warranty. The Navigation Provider Products are provided to you "as is", and you agree to use them at your own risk. The Navigation Provider and its licensors including the licensors, service providers, channel partners and suppliers, and affiliated companies of Navigation Provider and its licensors, make no guarantees, representations or warranties of any kind, express or implied, arising by law or otherwise, including but not limited to, content, quality, accuracy, completeness, effectiveness, reliability, merchantability, fitness for a particular purpose, usefulness, use or results to be obtained from the Navigation Provider Products, or that the Content or server will be uninterrupted or error-free. The Navigation Provider Products are intended to be used only as supplementary travel aids and must not be used for any purpose requiring precise measurement of direction, distance, location or topography. THE NAVIGATION PROVIDER MAKES NO WARRANTY AS TO THE ACCURACY OR COMPLETENESS OF THE MAP DATA OR OTHER CONTENT.

Disclaimer of warranty. THE NAVIGATION PROVIDER AND ITS LICENSORS, INCLUDING THE LICENSORS, SERVICE PROVIDERS, CHANNEL PARTNERS, SUPPLIERS AND AFFILIATED COMPANIES OF THE NAVIGATION PROVIDER AND ITS LICENSORS, DISCLAIM ANY WARRANTIES, EXPRESS OR IMPLIED, OF QUALITY, PERFORMANCE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NONINFRINGEMENT OF THE NAVIGATION PROVIDER PRODUCTS. NO ORAL OR WRITTEN ADVICE OR INFORMATION PROVIDED BY THE NAVIGATION PROVIDER OR ITS SUPPLIERS AND LICENSORS SHALL CREATE A WARRANTY, AND YOU ARE NOT ENTITLED TO RELY ON ANY SUCH ADVICE OR INFORMATION. THIS DISCLAIMER OF WARRANTIES IS AN ESSENTIAL CONDITION OF THIS AGREEMENT. Some Counties, Regions and Countries do not allow certain warranty exclusions, so to that extent the above exclusion may not apply to you.

Disclaimer of liability. THE NAVIGATION PROVIDER AND ITS LICENSORS, INCLUDING THE LICENSORS, SERVICE PROVIDERS, CHANNEL PARTNERS, SUPPLIERS AND AFFILIATED COMPANIES OF THE NAVIGATION PROVIDER AND ITS LICENSORS, SHALL NOT BE LIABLE TO YOU: IN RESPECT OF ANY CLAIM, DEMAND OR ACTION, IRRESPECTIVE OF THE NATURE OF THE CAUSE OF THE CLAIM, DEMAND OR ACTION ALLEGING ANY LOSS, INJURY OR DAMAGES, DIRECT OR INDIRECT, WHICH MAY RESULT FROM THE USE OR POSSESSION OF THE NAVIGATION PROVIDER PRODUCTS; OR FOR ANY LOSS OF PROFIT, REVENUE, CONTRACTS OR SAVINGS, OR ANY OTHER DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF YOUR USE OF OR INABILITY TO USE THE NAVIGATION PROVIDER PRODUCTS, ANY DEFECT IN THE CONTENT OR INFORMATION, OR THE BREACH OF THESE TERMS OR CONDITIONS, WHETHER IN AN ACTION IN CONTRACT OR TORT OR BASED ON A WARRANTY AND WHETHER RESULTING FROM THE USE, MISUSE, OR INABILITY TO USE THE NAVIGATION PROVIDER PRODUCTS OR FROM DEFECTS OR ERRORS IN THE APPLICATION, EVEN IF GARMIN OR ITS LICENSORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE NAVIGATION PROVIDER'S AND ITS LICENSORS' TOTAL AGGREGATE LIABILITY WITH RESPECT TO ITS OBLIGATIONS UNDER

THIS LICENCE AGREEMENT OR OTHERWISE WITH RESPECT TO THE APPLICATION OR THE CONTENT SHALL NOT EXCEED \$1.00 USD. Some Counties, Regions and Countries do not allow certain liability exclusions or damages limitations, so to that extent the above may not apply to you.

ANY CONTENT OR MATERIAL DOWNLOADED OR UPLOADED OR OTHERWISE OBTAINED THROUGH THE SOFTWARE IS DONE AT YOUR OWN DISCRETION AND RISK. YOU WILL BE SOLELY RESPONSIBLE FOR ANY DAMAGE TO YOUR ELECTRONIC COMMUNICATION DEVICE OR ANY LOSS OF DATA THAT MAY RESULT FROM THE DOWNLOAD OR UPLOAD OF ANY SUCH CONTENT OR MATERIAL OR THE USE OF THE SOFTWARE.

Predictive Routing. Your Navigation Solution may have a "predictive routing" feature called myTrends that identifies your driving routines. If it does have this feature, when your device predicts a route, it will display your estimated time to destination and relevant traffic information regarding the predicted route. Information related to your driving routines would be accessible to any other person who uses your device. If you do not want your device to predict your routes or display information related to predicted routes, you may turn off myTrends by accessing your navigation system's Settings menu.

Disclaimer of Endorsement; Change of Content Providers. Reference to any products, services, processes, hypertext links to third parties or other Content by trade name, trademark, manufacturer, supplier or otherwise does not necessarily constitute or imply its endorsement, sponsorship or recommendation by the Navigation Provider or its licensors. Product and service information are the sole responsibility of each individual vendor. The HERE and H logos are trademarks or registered trademarks of HERE Global B.V. and may not be used in any commercial manner without the prior written consent of HERE. Content providers may be changed by the Navigation Provider during the term of this Agreement, and your experience with the Content provided by a new provider may not duplicate your experience with the previous Content supplier.

Export control. You agree not to export from anywhere any part of the Content or any direct product thereof except in compliance with and with all licences and approvals required under, applicable export laws, rules and regulations. You understand and acknowledge that this product, application or software may not be transferred directly or indirectly to Crimea, Crimean individuals or Crimean entities.

Legal Compliance. You represent and warrant that (i) you are not located in a country that is subject to a US Government embargo, or has been designated by the US Government as a "terrorist supporting" country, and (ii) you are not listed on any US Government list of prohibited or restricted parties.

Indemnity. You agree to indemnify, defend and hold the Navigation provider and its licensors, including the respective licensors, service providers, channel partners, suppliers, assignees, subsidiaries, affiliated companies, and the respective officers, directors, employees, shareholders, agents and representatives of the Navigation Provider and its licensors, free and harmless from and against any liability, loss, injury (including injuries resulting in death), demand, action, cost, expense, or claim of any kind or character, including but not limited to attorney's fees, arising out of or in connection with any use or possession by you of the Navigation Provider Products.

Map Data. Use of the Map Data is subject to certain restrictions and/or requirements imposed by third-party suppliers and/or

governmental or regulatory authorities, and in the case of HERE Data, as further set forth at <https://legal.here.com/en-gb/terms/general-content-supplier-terms-and-notice>.

Term. This Agreement is effective until such time as (i) if applicable, your subscription term is either terminated (by you or by the Navigation Provider) or expires, or (ii) the Navigation Provider terminates this Agreement for any reason, including, but not limited to, if the Navigation Provider finds that you have violated any of the terms of this Agreement. In addition, this Agreement shall terminate immediately upon the termination of an agreement between the Navigation Provider and any third party from whom the Navigation Provider (a) obtains services or distribution necessary to support the Navigation Provider Products, or (b) licenses Content. You agree, upon termination, to destroy all copies of the Content. The Disclaimers of Warranty and Liability set out above shall continue in force even after any termination.

Entire agreement. These terms and conditions constitute the entire agreement between the Navigation Provider and its licensors, including the licensors, service providers, channel partners, suppliers and affiliated companies of the Navigation Provider and its licensors, and you pertaining to the subject matter hereof, and supersedes in their entirety any and all written or oral agreements previously existing between us with respect to such subject matter.

Governing law.

(a) For European Union HERE Data

The above terms and conditions shall be governed by the laws of the Netherlands, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of the Netherlands for any and all disputes, claims and actions arising from or in connection with the HERE Data provided to you hereunder.

(b) For North American HERE Data and other non-European Union HERE Data

The above terms and conditions shall be governed by the laws of Illinois, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of Illinois for any and all disputes, claims and actions arising from or in connection with the HERE Data provided to you hereunder.

(c) For disputes, claims and actions not related to the HERE Data

The above terms and conditions shall be governed by the laws of Kansas, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of Kansas for any and all disputes, claims and actions arising from or in connection with the Application or Content. Any translation of this Agreement from English is provided as a convenience only. If this Agreement is translated into a language other than English and there is a conflict of terms between the English version and the other language version, the English version will control.

Map Data Government End Users.

If the End User is an agency, department, or other entity of the United States Government, or funded in whole or in part by the U.S. Government, then use, duplication, reproduction, release, modification, disclosure or transfer of the Map Data is subject to restrictions as set forth in DFARS 252.227-7014(a)(1) (JUN

1995) (DOD commercial computer software definition), DFARS 27.7202-1 (DOD policy on commercial computer software), FAR 52.227-19 (JUN 1987) (commercial computer software clause for civilian agencies), DFARS 252.227-7015 (NOV 1995) (DOD technical data - commercial items clause); FAR 52.227-14 Alternates I, II, and III (JUN 1987) (civilian agency technical data and noncommercial computer software clause); and/or FAR 12.211 and FAR 12.212 (commercial item acquisitions), as applicable. In case of conflict between any of the FAR and DFARS provisions listed herein and this Licence Agreement, the construction that provides greater limitations on the Government's rights shall control. The contractor/manufacturer is HERE North America LLC, 425 West Randolph Street, Chicago, Illinois 60606 USA.

The HERE and H logos are trademarks in the U.S. and other countries. All other company names and trademarks mentioned or referenced in this documentation are the properties of their respective owners. All rights reserved.

Trademark notices

Garmin® and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. ecoRoute™, myTrends™ and trafficTrends™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc., and any use of such name by Garmin is under licence. All other company names and trademarks mentioned or referenced in this documentation are the properties of their respective owners. All rights reserved.

Table of contents

Getting started	1	Taking a detour	5
Navigation System	1	Stopping the route	5
Status bar icons	1	Using suggested routes	5
Using the on-screen buttons	1	About exit services	5
Removing a shortcut	1	Finding exit services	5
Adding a shortcut	1	Navigating to an exit	5
Using multi-touch controls	1	Avoiding road features	6
Updating the software	1	About custom avoidances	6
Updating map data	1	Avoiding an area	6
Finding locations	2	Avoiding a road	6
About locations	2	Disabling a custom avoidance	6
Finding a location by category	2	Deleting custom avoidances	6
Finding a location using the search bar	2	Enabling advanced detours	6
Changing the search area	2	Taking a detour	6
Search tools	2	Custom points of interest	6
Finding an address	2	Installing POI Loader software	6
Finding a junction	3	Installing custom points of interest	6
Finding a town	3	Using the POI Loader Help Files	7
Finding a location using coordinates	3	Find Extras	7
Starting a route by using the map	3	Map pages	7
Finding a location using quick search	3	Customising the map	7
Saving a home location	3	Customising the map layers	7
Going home	3	Viewing the trip log	7
Editing your home location information	3	Changing the map data field	7
Finding recently found places	3	Customising map buttons	7
Clearing the list of recently found places	4	Changing the map perspective	7
Finding parking	4	Viewing Route Activity	7
Setting a simulated location	4	Viewing a route summary	7
Saving Locations	4	Viewing the next turn	8
Saving a Location	4	Viewing traffic alerts	8
Saving your current location	4	Viewing junctions	8
Starting a route to a favourite location	4	Viewing the trip information page	8
Editing a favourite location	4	Getting directions to your current location	8
Assigning categories to a saved location	4	Viewing current location information	8
Navigation	4	Finding nearby services	8
Starting a route	4	Using the apps	8
Previewing multiple routes	4	Searching help topics	8
Your route on the map	5	About ecoRoute	8
Using the Map	5	Setting Up the Vehicle	8
Adding a Point to a Route	5	Calibrating the fuel economy	8
		Changing the fuel price	9
		About ecoChallenge	9
		Viewing fuel economy information	9
		Mileage reports	9
		Resetting ecoRoute™ Information	9
		Planning a trip	9
		Scheduling a trip	10
		Navigating to a saved trip	10
		Editing a saved trip	10

- Saving trip logs 10
- Viewing previous routes and destinations 10
- Viewing the weather forecast 10
 - Viewing weather near a different town 10
- Viewing Road Weather 10
- Finding petrol stations and prices 11
- Dynamic Parking 11
- About traffic 11**
 - Traffic data using INRIX Traffic Service 11
 - FM TMC traffic 11
 - About the traffic icon 11
 - Traffic on your route 11
 - Viewing traffic on your route 11
 - Manually avoiding traffic on your route 12
 - Taking an alternative route 12
 - Viewing traffic on the map 12
 - Traffic in your area 12
 - Searching for traffic delays 12
 - Viewing a traffic incident on the map 12
 - Understanding traffic data 12
- Customising the device 12**
 - Map and vehicle settings 12
 - Enabling maps 12
 - Navigation settings 12
 - Changing the route calculation mode 13
 - Display Settings 13
 - Changing the Colour Mode 13
 - Traffic Settings 13
 - trafficTrends 13
 - Disabling trafficTrends 13
 - Units and time settings 13
 - Language and Keyboard Settings 13
 - Device and privacy settings 13
 - Proximity alerts settings 14
 - Restoring settings 14

Getting started

⚠ WARNING

See the *Safety Precautions and Important Information* in the KENWOOD system instruction manual for product warnings and other important information.

NOTE: the screenshots shown in this manual may not exactly match the screens on your navigation system. The images used in this manual are intended for reference only.

Navigation System

For complete audio system information, see the KENWOOD system instruction manual.



① Opens the navigation system when selected.

Status bar icons

The status bar is at the top of the main menu. The status bar icons display information about features on the device. You can select some icons to change settings or view additional information.

	GPS and GLONASS signal status NOTE: gLONASS reception is not available on all device models.
	Current time
	INRIX Traffic Service status

Using the on-screen buttons

- Select to return to the previous menu screen.
- Hold to quickly return to the main menu.
- Select or to see more choices.
- Hold or to scroll faster.

- Select to see a menu of options for the current screen.

Removing a shortcut

- 1 Select **Where To?** > > **Remove Shortcut(s)**.
- 2 Select a shortcut to remove.
- 3 Select the shortcut again to confirm.
- 4 Select **Save**.

Adding a shortcut

You can add shortcuts to the Where To? menu. A shortcut can point to a location, a category, or a search tool.

The Where To? menu can contain up to 36 shortcut icons.

- 1 Select **Where To?** > **Personalise**.
- 2 Select an item.

Using multi-touch controls

You can use multi-touch controls to change the map view while using the navigation map.

NOTE: this feature is not available on all models.

- Pinch two fingers together on the screen to zoom out.
- Spread two fingers on the screen to zoom in.

Updating the software

Before you can update the navigation system software, you must have a USB mass storage device and an Internet connection.

- 1 Go to <http://www.kenwood.com/cs/ce/firmware/>.
- 2 Enter the model name for your device.

Updating map data

You can purchase updated map data from Garmin®.

- 1 Go to www.garmin.com/kenwood.
- 2 From the **Map Updates** section, select **Update**.
- 3 Follow the on-screen instructions.

Finding locations

About locations

The detailed maps loaded in your device contain locations, such as restaurants, hotels and vehicle services. You can use categories to browse for nearby businesses and attractions.

Finding a location by category

- 1 Select **Where To?**.
- 2 Select a category or select **Categories**.
- 3 If necessary, select a subcategory.
- 4 Select a location.

Searching within a category

To narrow your search results, you can search within some categories.

- 1 Select **Where To?**.
- 2 Select a category or select **Categories**.
- 3 If necessary, select a subcategory.
- 4 If necessary, enter all or part of the name in the search bar.

Calling a location

Before you can use this feature, you must connect your compatible mobile phone using Bluetooth® wireless technology.

- 1 Select **Where To? > Categories**.
- 2 Select a location.
- 3 Select **i**.
- 4 Select **Call**.

Finding a location using the search bar

You can use the search bar to search for locations by entering a category, brand name, address or town name.

- 1 Select **Where To?**.
- 2 Select **Enter Search** in the search bar.
- 3 Enter all or part of the search term.
Suggested search terms appear below the search bar.
- 4 Select an option:
 - To search for a type of business, enter a category name (for example, "cinemas").
 - To search for a business name, enter all or part of the name.

- To search for an address near you, enter the house number and street name.
- To search for an address in another town, enter the house number, street name, town and county.
- To search for a town, enter the town and county.
- To search for coordinates, enter latitude and longitude coordinates.

5 Select an option:

- To search using a suggested search term, select the term.
- To search using the text you entered, select **Q**.

6 If necessary, select a location.

Changing the search area

- 1 From the main menu, select **Where To?**.
- 2 Select **Searching near:**.
- 3 Select an option.

Search tools

Search tools allow you to search for specific types of locations by responding to on-screen prompts.

Finding an address

NOTE: the order of the steps may change depending on the map data loaded on your device.

- 1 Select **Where To? > Address**.
- 2 If necessary, select **County or Country** to change the search area.
- 3 Select an option:
 - To narrow your search to a city in the search area, select **Spell Town**.
 - To narrow your search to a postcode in the search area, select **Enter Post Code**.
 - To search for an address in all cities and postcodes in the search area, select **Search All**.
- 4 Follow the on-screen instructions to enter address information.
- 5 Select the address.

Finding a junction

You can search for a junction between two streets, motorways, or other roads.

- 1 Select **Where To? > Categories > Junctions**.
- 2 Follow the on-screen instructions to enter street information.
- 3 Select the junction.

Finding a town

- 1 Select **Where To? > Categories > Towns**.
- 2 Select an option:
 - Select a town from the list of nearby town.
 - To search near another location, select **Searching near:** ([Changing the search area](#)).
 - To search for a town by name, select **Enter Search**, enter a town name, and select **Q**.

Finding a location using coordinates

You can find a location using latitude and longitude coordinates.

- 1 Select **Where To? > Categories > Coordinates**.
- 2 If necessary, select **≡ > Format**, select the correct coordinate format for the type of map you are using, and select **Save**.
- 3 Select the latitude coordinate.
- 4 Enter the new coordinate and select **Done**.
- 5 Select the longitude coordinate.
- 6 Enter the new coordinate and select **Done**.
- 7 Select **View on Map**.

Starting a route by using the map

You can start a route by selecting a location from the map.

- 1 Select **View Map**.
- 2 Drag and zoom the map to display the area to search.
- 3 If necessary, select **Q** to filter the displayed points of interest by category. Location markers (📍 or a blue dot) appear on the map.
- 4 Select an option:

- Select a location marker.
- Select a point, such as a street, junction or address location.

- 5 Select **Go!**.

Finding a location using quick search

After you have performed a search for a point of interest, certain categories may display a Quick Search list that displays the last four destinations you selected.

- 1 Select **Where To?**.
- 2 Select a category or select **Categories**.
- 3 If applicable, select a destination from the Quick Search list.
- 4 If necessary, select the appropriate destination.

Saving a home location

You can set your home location for the location you return to most often.

- 1 Select **Where To? > ≡ > Set Home Location**.
- 2 Select **Enter My Address, Use Current Location** or **History**.

The location is saved as "Home" in the History menu.

Going home

Select **Where To? > Go Home**.

Editing your home location information

- 1 Select **Where To? > Favourites > Home**.
- 2 Select **i**.
- 3 Select **≡ > Edit**.
- 4 Enter your changes.
- 5 Select **Done**.

Finding recently found places

Your device stores the last 50 locations you have found.

- 1 Select **Where To? > History**.
- 2 Select a location.

Clearing the list of recently found places

Select **Where To?** > **History** >  > **Clear** > **Yes**.

Finding parking

- 1 Select **Where To?** > **Categories** > **Parking**.
- 2 Select a parking location.



Setting a simulated location

If you are indoors or not receiving satellite signals, you can use the GPS to set a simulated location.

- 1 Select **Settings** > **Navigation** > **GPS Simulator**.
- 2 From the main menu, select **View Map**.
- 3 Tap the map twice to select an area.
The address of the location appears at the bottom of the screen.
- 4 Select the location description.
- 5 Select **Set Location**.

Saving Locations

Saving a Location

- 1 Search for a location ([Finding a location by category](#)).
- 2 From the search results, select a location.
- 3 Select .
- 4 Select  > **Save**.

Saving your current location



- 1 From the map, select the vehicle icon.
- 2 Select **Save**.
- 3 Enter a name and select **Done**.
- 4 Select **OK**.

Starting a route to a favourite location

- 1 Select **Where To?** > **Favourites**.
- 2 If necessary, select a category or select **All Favourites**.
- 3 Select a location.
- 4 Select **Go!**.

Editing a favourite location



- 1 Select **Where To?** > **Favourites**.

- 2 If necessary, select a category.
- 3 Select a location.
- 4 Select .
- 5 Select  > **Edit**.
- 6 Select an option:
 - Select **Name**.
 - Select **Phone Number**.
 - Select **Categories** to assign categories to the saved location.
 - Select **Change Map Symbol** to change the symbol used to mark the saved location on a map.
- 7 Edit the information.
- 8 Select **Done**.

Assigning categories to a saved location

You can add custom categories to organise your saved locations.

NOTE: categories appear in the saved locations menu after you have saved more than 12 locations.

- 1 Select **Where To?** > **Favourites**.
- 2 Select a location.
- 3 Select .
- 4 Select  > **Edit** > **Categories**.
- 5 Enter one or more category names, separated by commas.
- 6 If necessary, select a suggested category.
- 7 Select **Done**.

Navigation

Starting a route

- 1 Search for a location ([About locations](#)).
- 2 Select a location.
- 3 Select **Go!**.
- 4 If necessary, select a route.

Previewing multiple routes

- 1 Search for a location ([Finding a location by category](#)).
- 2 From the search results, select a location.
- 3 Select **Routes**.

- 4 Select a route.
- 5 Select **Go!**.

Your route on the map









NOTICE

The speed limit feature is for information only and does not replace your responsibility to abide by all posted speed limit signs and to use safe driving judgement at all times. Garmin and JVC KENWOOD will not be responsible for any traffic fines or citations you receive for failing to follow all applicable traffic laws and signs.

The route is marked with a magenta line. A chequered flag marks your destination.


As you travel, the device guides you to the destination with voice prompts, arrows on the map and directions at the top of the map. If you depart from the original route, the device recalculates the route and provides new directions.

Using the Map

- 1 From the main menu, select **View Map**.
- 2 If the zoom controls are hidden, select the map to display the zoom controls.
- 3 Select the map.
- 4 Select an option:
 - To zoom in or out, select  or .
 - To rotate the map view, select .
 - To switch between North Up and 3-D views, select .
 - To add or remove map layers, select .
 - To view specific categories, select .
 - To centre the map on your current location, select .
 - To view shortcuts for map and navigation features, select .


Adding a Point to a Route

Before you can add a point, you must be navigating a route.


- 1 From the map, select  > **Where To?**.
- 2 Search for a location.
- 3 Select a location.
- 4 Select **Go!**.
- 5 Select **Add to Active Route**.

Taking a detour

While navigating a route, you can use detours to avoid obstacles ahead of you, such as construction zones.

While navigating, select  > **Detour**.

Stopping the route

From the map, select  > **Stop**.

Using suggested routes

Before you can use this feature, you must save at least one location and enable the travel history feature ([Device and privacy settings](#)).





Using the myTrends™ feature, your device predicts your destination based on your travel history, the day of the week and the time of day. After you have driven to a favourite location several times, the location may appear in the navigation bar on the map, along with the estimated time of travel and traffic information.

Select the navigation bar to view a suggested route to the location.


About exit services

NOTE: you must be on a major motorway or road to view exit services.



While navigating a route, you can find businesses and services near upcoming exits. Services are listed by category.

	Fuel
	Food
	Accommodation
	Toilets

Finding exit services

- 1 From the map, select  > **Exit Services**.
- 2 Use the arrows to select an upcoming exit.
- 3 Select an exit service tab.
- 4 Select a point of interest.

Navigating to an exit

- 1 From the map, select  > **Exit Services** > .
- 2 Select **Go!**.

Avoiding road features

- 1 Select **Settings > Navigation > Avoidances**.
- 2 Select the road features to avoid on your routes and select **Save**.

NOTE: when motorway avoidances are enabled, long-distance routes may still include motorways.

About custom avoidances

Custom avoidances allow you to avoid specific areas and sections of road. You can enable and disable custom avoidances as needed.

Avoiding an area

- 1 Select **Settings > Navigation > Custom Avoidances**.
- 2 If necessary, select **Add Avoidance**.
- 3 Select **Add Avoid Area**.
- 4 Select the upper left corner of the area to avoid and select **Next**.
- 5 Select the lower right corner of the area to avoid and select **Next**.
The selected area is shaded on the map.
- 6 Select **Done**.

Avoiding a road

- 1 Select **Settings > Navigation > Custom Avoidances**.
- 2 Select **Add Avoid Road**.
- 3 Select the starting point of the section of road to avoid and select **Next**.
- 4 Select the ending point of the road section and select **Next**.
- 5 Select **Done**.

Disabling a custom avoidance

You can disable a custom avoidance without deleting it.

- 1 Select **Settings > Navigation > Custom Avoidances**.
- 2 Select a created avoidance.
- 3 Select **≡ > Disable**.

Deleting custom avoidances

- 1 Select **Settings > Navigation > Custom Avoidances**.
- 2 Select an option:

- To delete all custom avoidances, select **X**.
- To delete one custom avoidance, select the avoidance and select **≡ > Delete**.

Enabling advanced detours

Select **Settings > Navigation > Advanced Detours**.

Taking a detour

Before you can take a detour, you must be navigating a route.

You can take a detour for a specified distance along your route or detour around specific roads. This is useful if you encounter construction zones, closed roads or poor road conditions.

- 1 From the map, select **≡ > Detour**.
- 2 Select an option.
 - To detour your route for a specific distance, select a distance.
 - To detour around a specific road on the route, select **Detour by Road(s) on Route**, and select a road around which to detour.

Custom points of interest

Custom POIs are customised points on the map. They can contain alerts that let you know if you are near a designated point or if you are travelling faster than a specified speed.

Installing POI Loader software

You can create or download custom POI lists on your computer and install them on your device using POI Loader software. You must use a USB mass storage device to load POIs.

- 1 Go to www.garmin.com/extras.
- 2 Click **Services & Utilities > POI Loader**.
- 3 Install the POI Loader onto your computer.

Installing custom points of interest

Before you can install custom points of interest, you must prepare POI lists for installation using the POI Loader application.

- 1 Connect a USB mass storage device to your computer.

- 2 On the USB mass storage device, create a new folder named Garmin.
- 3 Copy the custom POI files to the Garmin folder on the USB mass storage device.
- 4 Connect the USB mass storage device to your KENWOOD system.
- 5 On the KENWOOD system screen, select **Yes**.
- 6 Select **Custom POIs**.
- 7 Select **Install**.

The KENWOOD system imports the custom points of interest into the system storage.

Using the POI Loader Help Files

For more information on the POI loader, refer to the Help file.

With the POI loader open, click **Help**.

Find Extras


- 1 Select **Where To? > Categories > Custom POIs**.
- 2 Select a category.

Map pages

Customising the map

Customising the map layers

You can customise which data appears on the map, such as icons for points of interest and road conditions.

- 1 From the map, select .
- 2 Select **Map Layers**.
- 3 Select which layers you want to include on the map and select **Save**.

Viewing the trip log

Your device keeps a trip log, which is a record of the path you have travelled.


- 1 Select **Settings > Map & Vehicle > Map Layers**.
- 2 Select the **Trip Log** tick box.
- 3 Select **Save**.

Changing the map data field

- 1 From the map, select the data field in the lower left-hand corner.
- 2 Select a type of data to display.
- 3 Select **Save**.

Customising map buttons

You can include up to three icons on the right side of the main map.

- 1 Select **Settings > Map & Vehicle > Map Buttons**.
- 2 Select an icon and select **OK**.
- 3 Select .
- 4 Select a different icon.
- 5 Select **Save**.

Removing buttons from the map

You can remove all buttons from the right side of the map.

- 1 Select **Settings > Map & Vehicle > Map Buttons**.
- 2 Select an icon and select **OK**.
- 3 Select **Save**.

Changing the map perspective

- 1 Select **Settings > Map & Vehicle > Driving Map View**.
- 2 Select an option:
 - Select **Track Up** to display the map in two dimensions (2-D), with your direction of travel at the top.
 - Select **North Up** to display the map in 2-D with north at the top.
 - Select **3-D** to display the map in three dimensions.
- 3 Select **Save**.

Viewing Route Activity


Viewing a route summary

While navigating a route, you can view all of the turns and manoeuvres for your entire route and the distance between turns.

- 1 While navigating a route, select the text bar on the top of the map.
- 2 Select a turn.

The details for the turn appear. If available, an image of the junction appears for junctions on major roadways.


Viewing the entire route on the map

- 1 While navigating a route, select the navigation bar at the top of the map.
- 2 Select  > **Map**.

Viewing the next turn

While navigating a route, a preview of the next turn, lane change or other manoeuvre appears in the upper left corner of the map.

The preview includes the distance to the turn or manoeuvre and the lane in which you should be travelling, if available.

From the map, select  to view the next turn on the map.

Viewing traffic alerts


While navigating a route, a traffic alert may appear in the navigation bar.

Select the alert to view more information.

Viewing junctions

While navigating a route, you can view the junctions on major roadways. When you approach a junction in a route, the image of that junction appears briefly, if available.

NOTE: this feature is not available on all models.

From the map, select  to view the junction, if available.


Viewing the trip information page

The trip information page displays your speed and provides statistics about your trip.

NOTE: if you make frequent stops, leave the device turned on, so it can accurately measure elapsed time during the trip.


From the map, select **Speed**.

Resetting trip information

- 1 From the map, select **Speed**.
- 2 Select  > **Reset All**.
- 3 Select an option:
 - When not navigating a route, select **Select All** to reset every data field on the first page except the speedometer.
 - Select **Reset Trip Data** to reset the information on the trip computer.
 - Select **Reset Trip B** to reset the odometer.
 - Select **Reset Max. Speed** to reset the maximum speed.
- 4 Select **Reset**.

Getting directions to your current location

If you need to tell another person how to get to your current location, your device can give you a list of directions.

- 1 From the map, select the vehicle.
- 2 Select  > **Directions to Me**.


Viewing current location information

You can use the Where Am I? page to view information about your current location. This feature is helpful if you need to tell emergency personnel your location.

From the map, select  > **Where Am I?**

Finding nearby services

You can use the Where Am I? page to find nearby services, such as hospitals or police stations.

- 1 From the map, select  > **Where Am I?**
- 2 Select a category.

Using the apps

Searching help topics

Select **Apps** > **Help** > **Q**.

About ecoRoute

The ecoRoute™ feature calculates the fuel economy and the fuel price of navigating to a destination, and offers tools for improving fuel efficiency.

The data provided by the ecoRoute feature is an estimate only.

To receive more accurate fuel reports for your specific vehicle and driving habits, calibrate the fuel economy ([Calibrating the fuel economy](#)).

Setting Up the Vehicle

The first time you use the ecoRoute features, you must enter vehicle information.

- 1 Select **Apps** > **ecoRoute™**.
- 2 Follow the on-screen instructions.

Calibrating the fuel economy

You can calibrate the fuel economy to receive more accurate fuel reports for your

specific vehicle and driving habits. You should calibrate when you fill up your fuel tank.

- 1 Select **Apps** > **ecoRoute™** > **At the Pump**.
- 2 Enter the current fuel price.
- 3 Enter the amount of fuel the vehicle has used since the last time the fuel tank was filled.
- 4 Enter the distance you have travelled since the last time the fuel tank was filled.
- 5 Select **Next**.
The device calculates the average vehicle fuel economy.
- 6 Select **Save**.

Changing the fuel price

- 1 Select **Apps** > **ecoRoute™** > **At the Pump**.
- 2 Enter the current price of fuel, and select **Next**.
- 3 Select **Yes**.

About ecoChallenge

ecoChallenge helps you maximise the vehicle fuel economy by scoring your driving habits. The higher your ecoChallenge scores, the more fuel you save. ecoChallenge collects data and calculates a score whenever your vehicle is moving.

Viewing ecoChallenge scores

Select **Apps** > **ecoRoute™** > **ecoChallenge**.

About the ecoChallenge score

The leaf colour on the ecoChallenge icon changes depending on your performance in the challenge.


Total: displays an average of the speed, acceleration and braking score.

Speed: displays your score for driving your vehicle at the optimal speed for conserving fuel.

Acceleration: displays your score for smooth and gradual acceleration. You lose points for rapid acceleration.

Braking: displays your score for smooth and gradual braking. You lose points for hard braking.

Resetting the ecoChallenge scores

- 1 Select **Apps** > **ecoRoute™** > **ecoChallenge**.
- 2 Select  > **Reset**.
- 3 Select **Yes**.

Viewing fuel economy information

- 1 Select **Apps** > **ecoRoute™** > **Fuel Economy**.
- 2 Select a section of the graph to zoom in.

Mileage reports

Mileage reports provide the distance, the time, the average fuel economy and the fuel cost of navigating to a destination.

A mileage report is created for every route that you drive. If you stop a route on your device, a mileage report is created for the distance you travelled.

Exporting a mileage report


- 1 Connect a USB mass storage device to your KENWOOD unit.
- 2 Select **Apps** > **ecoRoute™** > **Mileage Report**.
- 3 Select **Export** to export and save a report to the USB mass storage device.

Resetting ecoRoute™ Information

- 1 Select **Apps** > **ecoRoute™** > **Vehicle Profile**.
- 2 Select **Reset**.
- 3 Select **Yes**.

Planning a trip

You can use the trip planner to create and save a trip with multiple destinations.

- 1 Select **Apps** > **Trip Planner**.
- 2 Select **New Trip**.
- 3 Select **Select Start Location**.
- 4 Search for a location ([Finding a location by category](#)).
- 5 Select **Select**.
- 6 To add additional locations, select .
- 7 Search for a location.
- 8 Select **Select**.
- 9 Select **Next**.
- 10 Enter a name and select **Done**.

Scheduling a trip

You can add scheduling information to each location in your trip, including the desired arrival time and layover duration at each location. This can help you plan your departure to reach locations in your trip on time.

- 1 Select **Apps > Trip Planner**.
- 2 Select a trip.
- 3 Select a location.
- 4 Select **Departure Time** or **Arrival Time**.
- 5 Select a date and time, and select **Save**.
- 6 Select **Duration**.
- 7 Select the amount of time you intend to spend at the location, and select **Save**.
- 8 If necessary, repeat steps 3 to 7 for each location.

Navigating to a saved trip

- 1 Select **Apps > Trip Planner**.
- 2 Select a saved trip.
- 3 Select **Go!**.
- 4 Select your next destination.
- 5 If prompted, select a route.

Editing a saved trip

- 1 Select **Apps > Trip Planner**.
- 2 Select a saved trip.
- 3 Select **≡**.
- 4 Select an option:
 - Select **Edit Destinations** to add and delete a location, or to change the order of locations.
 - Select **Delete Trip**.
 - Select **Rename Trip**.
 - Select **Optimise Order** to arrange the stops on your trip in the most-efficient order.
 - Select **Route Preference** to change the route calculation mode for your trip.

Saving trip logs

Trip logs are recorded while you navigate a route.

NOTE: trip log data is saved as a .gpx file.

- 1 Connect a USB mass storage device to your KENWOOD unit.

- 2 Select **Apps > My Data > Manage Trip Log**.
- 3 Select a trip log segment or select **View All Segments**.
- 4 Select **Share** to export to the USB mass storage device.

Viewing previous routes and destinations

Before you can use this feature, you must enable the travel history feature (**Device and privacy settings**).

You can view your previous routes and places you have stopped on the map.

Select **Apps > Where I've Been**.

Viewing the weather forecast

Before you can use this feature, your device must be connected using Bluetooth to access connected services. This feature is not available in all areas.

- 1 Select **Apps > Weather**.
- 2 Select a day.

The detailed forecast for that day appears.

Viewing weather near a different town

- 1 Select **Apps > Weather > Current Location**.
- 2 Select an option:
 - To view weather for a favourite town, select a town in the list.
 - To add a favourite town, select **Add Town**, and enter a town name.

Viewing Road Weather

Before you can use this feature, your device must be connected using Bluetooth wireless technology to access connected services. This feature is not available in all areas.


- 1 Select **Apps > Road Weather**.

Weather events that affect road conditions appear on the map.
- 2 Select a weather event to view details about the event.

Finding petrol stations and prices

Before you can use this feature, your device must be connected using Bluetooth to access connected services.

You can find nearby petrol stations and compare fuel prices.

- 1 Select **Apps > Fuel Prices**.
- 2 If necessary, select  **> Fuel Type**, select a fuel type, and select **Save**.
- 3 Select a petrol station.

Dynamic Parking

Before you can use this feature, your device must be connected using Bluetooth to access connected services. This feature is not available in all areas.

You can find detailed parking information, including parking availability in nearby garages and pricing information.

- 1 Select **Apps > Dynamic Parking**.
- 2 Select a parking location.

About traffic

NOTICE

Garmin and JVC KENWOOD are not responsible for the accuracy or timeliness of traffic information.

Your navigation system can receive traffic information using the built-in traffic receiver or a subscription to INRIX® Traffic Service. The traffic receiver must be in data range of a station transmitting traffic data to receive traffic information. The traffic subscription activates automatically after your navigation system acquires satellite signals while receiving traffic signals from the service provider. When receiving INRIX traffic information, FM TMC information is not displayed. You can add other subscriptions at any time. For information about traffic receivers and coverage areas, go to www.garmin.com/kenwood.

NOTE: INRIX Traffic Service and FM TMC Traffic are not available on all models or in all areas.

Traffic data using INRIX Traffic Service

You can purchase a traffic subscription to receive traffic data using INRIX traffic service. When your navigation system is connected to INRIX and within a traffic coverage area, your system begins displaying traffic information. Traffic data is not available in all areas or regions.

See the KENWOOD Traffic Powered By INRIX™ application for INRIX traffic subscription information.

FM TMC traffic

FM Traffic Message Channel (TMC) traffic receivers receive traffic information broadcast over the FM Radio Data System. The FM TMC subscription activates automatically after your navigation system acquires satellite signals while receiving traffic signals from the service provider. You can add other FM TMC subscriptions at any time.

NOTE: the availability of FM TMC depends on your region and may require the purchase of a subscription.

For information about traffic receivers and coverage areas, go to www.garmin.com/kenwood.

About the traffic icon

When you are receiving traffic information, a traffic icon appears on the map. The traffic icon changes colour to indicate the severity of traffic conditions.

Green: traffic is flowing freely.


Yellow: traffic is moving, but there is a delay. There is moderate traffic congestion.

Red: traffic is not moving or moving very slowly. There is a severe delay.

Grey: traffic information is not available.

Traffic on your route



Viewing traffic on your route

- 1 While navigating a route, select .
- 2 Select **Traffic On Route**.


A list of traffic events appears, organised by their location on the route.

- 3 Select an event.

Manually avoiding traffic on your route

- 1 From the map, select .
- 2 Select **Traffic On Route**.
- 3 If necessary, use the arrows to view other traffic delays on your route.
- 4 Select  > **Avoid**.

Taking an alternative route

- 1 While navigating a car route, select .
- 2 Select **Alternative Route**.
- 3 Select a route.


Viewing traffic on the map

The Traffic map shows colour-coded traffic flow and delays on nearby roads.


- 1 From the map, select .
- 2 Select **Traffic Conditions**.

Traffic in your area

Searching for traffic delays


- 1 From the map page, select .
- 2 Select **Traffic Conditions** > **Q**.
- 3 Select an item in the list.
- 4 If there is more than one delay, use the arrows to view additional delays.

Viewing a traffic incident on the map

- 1 From the map, select .
- 2 Select **Traffic Conditions**.
- 3 Select a traffic icon.

Understanding traffic data

The traffic legend explains the icons and colours used on the traffic map.

- 1 From the map, select  > **Traffic**.
- 2 Select **Traffic Legend**.

Customising the device

Map and vehicle settings

To open the Map and Vehicle settings, from the main menu, select **Settings** > **Map & Vehicle**.

Vehicle: sets the icon that represents your position on the map.

Driving Map View: sets the perspective on the map.

Map Detail: sets the level of detail on the map. More detail may cause the map to draw slower.

Map Theme: changes the colour of the map data.

Map Buttons: sets which icons are included on the map. Up to three icons can be included on the map.

Map Layers: sets the data that appears on the map page ([Customising the map layers](#)).

Dashboards: sets the map dashboard layout.

Auto Zoom: automatically selects the zoom level for optimal use of your map. When disabled, you must zoom in or out manually.

Audible Speed Alerts: alerts you when your vehicle is exceeding the speed limit.

NOTE: this feature is not available in all areas.

myMaps: sets which installed maps the device uses.

Enabling maps

You can enable map products installed on your device.

- 1 Select **Settings** > **Map & Vehicle** > **myMaps**.
- 2 Select a map.

Navigation settings

To open the Navigation settings page, from the main menu, select **Settings** > **Navigation**.

Calculation Mode: sets the route calculation method.

Avoidances: sets road features to avoid on a route.

Custom Avoidances: allows you to avoid specific roads or areas.

Advanced Detours: sets the length of a detour.

Safe Mode: disables all functions that require significant operator attention and could become a distraction while driving.

Voice Prompts: enables voice prompts.

GPS Simulator: stops the device from receiving GPS and GLONASS signals.

Changing the route calculation mode

- 1 Select **Settings > Navigation > Calculation Mode**.
- 2 Select an option:
 - Select **Faster Time** to calculate routes that are faster to drive but can be longer in distance.
 - Select **Shorter Distance** to calculate routes that are shorter in distance but can take more time to drive.
 - Select **Less Fuel** to calculate routes that are more fuel-efficient.
- 3 Select **Save**.

Display Settings

Select **Settings > Display**.

Colour Mode: allows the device to display day or night colours.

Changing the Colour Mode

- 1 Select **Settings > Display > Colour Mode**.
- 2 Select an option:
 - To use a light background, select **Day**.
 - To use a dark background, select **Night**.
 - To allow the device to display day or night colours automatically, based on the time of day, select **Auto**.

Traffic Settings

From the main menu, select **Settings > Traffic**.

Traffic: enables traffic.

Subscriptions: lists the current traffic subscriptions.

trafficTrends™: enables the trafficTrends™ feature ([trafficTrends](#)).

Traffic Voice Prompts: enables voice prompts for traffic events.

trafficTrends

When the trafficTrends feature is enabled, your device uses historic traffic data to calculate more-efficient routes.

NOTE: different routes may be calculated based on traffic trends for the day of the week or the time of day.

Disabling trafficTrends

To prevent your device from recording traffic data, you must disable trafficTrends.

Select **Settings > Traffic > trafficTrends™**.

Units and time settings

To open the Units and Time settings page, from the main menu, select **Settings > Units & Time**.

Current Time: sets the device time.

Time Format: allows you to select a 12-hour, 24-hour or UTC display time.

Units: sets the unit of measure used for distances.

Language and Keyboard Settings

To open the Language and Keyboard settings, from the main menu, select **Settings > Language & Keyboard**.

NOTE: to change the text language settings, see the KENWOOD system instruction manual.

Voice Language: sets the language for voice prompts.

Keyboard Language: sets the language for your keyboard.

Keyboard Layout: sets the keyboard layout.

Device and privacy settings

To open the Device settings page, from the main menu, select **Settings > Device**.

About: displays the software version number, the unit ID number and information on several other software features.

Travel History: allows the device to record information for the myTrends ([Using suggested routes](#)), [Where I've Been](#) ([Viewing previous routes and](#)

destinations) and Trip Log (Viewing the trip log) features.

Clear Travel History: clears your travel history from the navigation system.

Update Map: exports data from the navigation unit for updates (Updating map data).

Proximity alerts settings

NOTE: you must have custom points of interest (POIs) loaded for proximity points alerts to display.

NOTE: this feature is not available in all areas.


Select **Settings > Proximity Alerts**.

Audio: sets the style of alert that plays when you approach proximity points.

Alerts: sets the type of proximity points for which alerts are played.

Restoring settings

You can restore a category of settings or all settings to the factory default values.

- 1 Select **Settings**.
- 2 If necessary, select a settings category.
- 3 Select  **> Restore**.
- 4 Select **Yes**.

To download free navigation software updates and purchase updated maps for your product, go to www.garmin.com/kenwood.

